


HOW TO USE YOUR SAMSUNG DOOR KEYPAD

1. Press the silver bar to activate.



2. Press the TWO numbers that show.



3. Press the corresponding code provided to you.



* The batteries will make a "warning" sound when getting low. Please replace them immediately and do not wait until you aren't able to get in your room due to dead batteries. See your ADL for batteries.